

- Explore the specific conditions on the property in-person
- Gather information to determine which living shoreline option to select
- The property's characteristics may make certain living shoreline options unsuitable
 - For example, submerged oyster shell beds are not recommended in high wave energy or deep water





Photo: Texas Parks and Wildlife Department

Visual Site Assessment Components

WATER

Wave energy

Fetch Water depth

Salinity

SHORE

Shoreline type

Slope

Erosion Rate

OTHER

Neighboring property conditions Personal preference

	this site assessment worksheet to better understand the conditions on your property that may affect the success ected living shoreline and also to assist you to better identify preferences for your living shoreline design.
1.	Type of Shoreline: Natural, Armored, Marsh, Beach, Flat or other
	Comments:
2.	Slope: No Slope, Gradual Slope, or Steep Slope, Bluff
	Comments:
3.	Erosion Rate: No Erosion, Low Erosion, Moderate Erosion, or High Erosion
	Comments:
4.	Wave Energy: Low Energy, Moderate Energy, or High Wave Energy
	Comments:
5.	Fetch: Short fetch; Moderate fetch, or Long fetch
	Comments:
6.	Water Depth Immediately Off-Shore: Shallow, Moderate Depth or Deep
	Comments:
7.	Salinity: Saline, Brackish or Freshwater
	Comments:
8.	Neighboring Property Conditions a. What are the conditions on neighboring property's shorelines?
	Do they have a bulkhead or seawall or a more nature shoreline? Are they experiencing erosion? How severe?
	d. Are they interested in using a living shoreline to prevent erosion?
	Comments:
9.	Do You Have a Personal Preference for Living Shoreline Features? For example, do you want the living shoreline to increase biodiversity, provide fish habitat, provide water access, reduce erosion, improve water quality, or look natural?
	If so, what?
10.	Do You Have a Recreational Structure such as a Pier, Dock, or Boat Ramp to Consider When Selecting a Living Shoreline?
	If so, what?

Guidance Document Appendix B: Visual Site Assessment Worksheet







Wave Energy

Wave energy is a strong erosional force caused by natural forces or human activity

Questions to help determine the wave energy at a site:

- Is the property sheltered or far from boat traffic? Is it a mud or tidal flat? LOW
- Is there shell hash on the shore? MODERATE
- Does the property border a shipping channel or have steep bluffs? HIGH



Photos: GLO

Type of Shoreline

The type of shoreline on the property will help determine which living shoreline option is the most practical

Questions to help determine the shoreline type:

- Is the shoreline a marsh, beach, tidal flat, or mud flat?
- Is the shoreline sand or fragmented shells?
- Does the shoreline have a hard stabilization structure in place? For example, is there a bulkhead?





Slope

The grade or steepness of the shoreline

Flat or gradual sloping shorelines are best for marsh plantings, while steeper slopes might require a rock alternative

Grading to flatten the land and prepare it for installation might be necessary

Slope types:

- Flat
- Gradual
- Moderate
- Steep



Steep sloped bluff

Flat slope





Photo: Galveston Bay Foundation

Salinity

Freshwater mixing with saltwater produces a range of salinity

The salinity determines which vegetation will grow best and whether oysters will be a successful part of the living shoreline design

Salinity options:

- Saltwater
- Freshwater
- Brackish

Living shoreline option based on property's characteristics

		Shoreline Type			Wave Energy			Water Depth		
Category	Option	Existing Bulkhead	Marsh	Beach Sand / Shell Hash	Low	Moderate	High	Shallow	Moderate	Deep
Soft Stabalization	Marsh Vegetation Plantings	X	√	•	√	•	X	√	•	X
	Coir Logs	X	√	√	√	X	X	√	Х	X
	Submerged Oyster Shell Beds	•	√	√	√	√	X	√	•	X
	Reef Balls	•	√	√	√	√	√	✓	√	X
Hybrid Stabilization	Articulated Mats or Blocks	X	√	√	√	√	•	✓	•	X
	Breakwater with Marsh Plantings	√	√	•	•	√	√	√	√	√
	Riprap with Marsh Plantings	√	√	•	•	•	X	√	•	Х

√	Best management strategy
•	Potential management strategy
X	Generally not recommended



Living shoreline option based on property's characteristics

		Shoreline Type			,	Wave Energ	У	Water Depth		
Category Ontion		Existing Bulkhead	Marsh	Beach Sand / Shell Hash	Low	Moderate	High	Shallow	Moderate	Deep
Soft Stabalization	Marsh Vegetation Plantings	X	√	•	√	•	X	√	•	X
	Coir Logs	X	√	√	√	X	Х	√	Х	X
	Submerged Oyster Shell Beds	•	√	√	√	√	Х	√	•	X
	Reef Balls	•	√	√	√	√	√	✓	√	X
Hybrid Stabilization	Articulated Mats or Blocks	Х	√	√	√	√	•	✓	•	X
	Breakwater with Marsh Plantings	√	✓	•	•	√	√	✓	√	√
	Riprap with Marsh Plantings	√	√	•	•	•	X	√	•	Х

√	Best management strategy
•	Potential management strategy
X	Generally not recommended



Living shoreline option based on property's characteristics

		Shoreline Type		Wave Energy			Water Depth			
Category	Option	Existing Bulkhead	Marsh	Beach Sand / Shell Hash	Low	Moderate	High	Shallow	Moderate	Deep
Soft Stabalization	Marsh Vegetation Plantings	X	√	•	√	•	X	√	•	Х
	Coir Logs	Х	√	\checkmark	√	X	X	√	Х	Х
	Submerged Oyster Shell Beds	•	√	√	√	√	Х	√	•	Х
	Reef Balls	•	√	√	√	√	√	√	√	Х
Hybrid Stabilization	Articulated Mats or Blocks	X	√	√	√	√	•	✓	•	X
	Breakwater with Marsh Plantings	√	√	•	•	√	√	√	√	√
	Riprap with Marsh Plantings	√	√	•	•	•	Х	√	•	Х

√	Best management strategy
•	Potential management strategy
X	Generally not recommended



Oak Island


Property Owner





Oak Island

Property Owner





Photos: Galveston Bay Foundation

Oak Island

Living Shoreline Installed:

 Rock breakwater with marsh vegetation planting







Living Shoreline Options

The GLO has identified four broad categories of living shorelines commonly used along the Texas coast

Soft Stabilization







Retrofit: Hybrid Stabilization

Hybrid Stabilization



Photos: GLO

Retrofit: Soft Stabilization



Soft Stabilization



Photo: GLO

- Non-structural in nature and usually involve planting marsh grasses along the existing shoreline
- Marsh grass plantings
 - Root systems hold soil in place to help reduce erosion
 - Plant shoots reduce wave energy and increase sediment deposition
- Coir logs
 - Most effective in low energy environments above the mean high tide line



Photo: GLO



Photo: Delaware Living Shorelines

Hybrid Stabilization

Incorporate the materials used in soft techniques with hard features to provide additional erosion protection

Options:

- Submerged Oyster Shell Beds
- Reef Balls
- Articulated Blocks or Mats with Marsh Plantings
- Riprap with Marsh Plantings
- Breakwater with Marsh Plantings



Photo: Mott MacDonald







Photo: Triton Environmental Solutions, LLC

Retrofit: Soft Stabilization

- Used in lower energy environments that already have a hard structure in place such as a bulkhead or seawall
- For environments that can support marsh vegetation without any additional offshore structure to protect the plants
- Vegetation is planted seaward of the existing hard structure





Retrofit: Hybrid Stabilization

- Used when there is an existing shoreline structure in place such as a bulkhead or seawall
- There may or may not be existing marsh plantings that need additional protection from an oyster reef, articulated blocks or mat, breakwater, or riprap.
- The living shoreline is installed seaward of the existing hard structure



Photo: GLO



Photo: Galveston Bay Foundation



Photo: GLO

Out of the 114 known living shoreline projects in Texas, there are...

